



FIXING INSTRUCTIONS **For all Bolt Down Anchors**

1. Select a suitable location on a solid, flat concrete surface.
2. Mark the hole positions on the concrete.
3. Drill at each position $\varnothing 16\text{mm}$ by a minimum of 60mm deep.
4. Gently push the outer fixing part, 'the shell' into the hole until it is flush with the surface.
5. Position the ground-anchor over the fixing holes.
6. Locate the M10 screw through the anchor and into the 'shell' and tighten up with a 6mm Allen key.
7. When all the fixings are tight, position a ball bearing into the hexagon hole in the bolt head, and hammer the ball into the head of the bolt until flush.
8. Finally, place a stainless steel cover over the head of each bolt and hammer into the hole in the anchor.

Installation is complete.