



INSTALLATION INSTRUCTIONS

ML – CP20

- Find a suitable location on a sound concrete or brick wall.
- Set out the positions of the units, usually 900mm to 1000mm apart.
- The height of the locking shackle should be 500 - 900mm from the ground.
- Mark the position of the top central hole.
- Drill a Ø5.5mm hole approx 50mm deep.
- Using a Rawl-plug and a 40mm wood screw, screw into the rawl-plug leaving 15mm of the screw protruding.
- Hang the ML-CP20 on the woodscrew.
- Mark the position of the other four holes and then remove the unit from the wall.
- Drill the marked holes Ø12mm - 100mm deep and fill with a suitable epoxy resin.
- Position the ML-CP20 on the wood screw and insert the M10 studs provided into the resin filled holes.
- Repeat for any other ML-CP20 that need installing
- Allow time for the resin to cure. Check the instructions supplied with the resin for approximate curing time.
- Secure the unit to the wall using the nuts provided. These should be tightened until the heads of the nuts 'shear' off. Repeat for all units.

Installation is complete.

